

imPower™

INSTALLATION & OPERATION



 **marathon**[®]
electric

ImPowerDealer.com



Marathon Electric offers a full line of motors for the pool, spa and bath markets. For quick installation, long life and easy serviceability, poolside contractors prefer our pool and spa motors.

Marathon designs motors for a variety of pool and spa applications: above-ground pool, in-ground pool, commercial pool, variable-speed, heat pumps and all other standard applications.

Our variable speed products consume up to 64% fewer watts than standard PSC induction motors. This not only saves the Earth's precious resources, but also saves the consumer hundreds of dollars per year in energy costs.

Why Choose Us?

Our fast response to customer questions, unmatched engineering expertise and the delivery speed that comes with maintaining a large inventory makes Marathon Electric ideally suited to meeting our customers' needs. In addition Marathon's focus on innovation keeps our customers on the leading edge of technology.

100 East Randolph St.
Wausau, WI 54402
800-683-9144

imPower™ Installation Guide
© Copyright 2010
Regal Beloit Corporation

The information in this document is subject to change without notice.

Rev 1.0 05/10

Marathon Electric is a Regal Beloit Company.



Table of Contents

Safety Considerations	4
Introduction	5
Removing the Existing Motor from Pump	6
Single Speed Connection with Timer	7
Two Speed Connections with Timer	9
Automation Controller Signal Line Connection	11
Changing Default Low Speed	14
imPower Motor Connection Diagramm	15

Please read the entire instruction manual before starting the installation.

Safety Considerations

The following definitions are used as safety considerations on the imPower pool filter pump motor. Please read and observe all of these safety concerns.

Please abide by all health and safety regulations governing pools by the state and local departments governing pool health and safety.

SAFETY SYMBOLS

 **WARNING** Warning indicates a hazardous situation which, if not avoided, could result in death or serious injury.

 **CAUTION** Caution indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

WARNING

Ground the motor in accordance with local and national electrical codes. Disconnect main power and wait 30 seconds prior to servicing motor. Topside interface enclosure must be securely fastened for safe operation.

CAUTION

Motor not intended for disassembly. Attempting to do so may result in pinching injury from strong rotor magnets.

CAUTION

Keep fingers and objects away from openings and rotating parts.

Introduction

The imPower motor is a permanent magnet alternating current (PMAC) electronically commutated motor (ECM), leveraging over 20 years of ECM technical and manufacturing experience. The motor can save up to 85% of electrical consumption due to this innovative motor design. This imPower motor is designed to replace existing full-rated pool filter pump motors rated at 3/4 HP 1.65 SF or up-rated motor at 1.0HP 1.25 SF.

This motor also features three selectable speeds either through the use of the patent pending auto speed switch feature, top panel push buttons, external multi-speed timers, or through external automation controls.

RB003

Model Number	5SME29DFT001
Voltage	208-230V (±10%)
Flange	Square
HP	1.0
Service Factor	1.25
High Speed	3450 RPM
Medium Speed	2600 RPM
Low Speed	1725 RPM
Weight	11 lbs

RB053

Model Number	5SME29DFT002
Voltage	208-230V (±10%)
Flange	Round/C-Face
HP	1.0
Service Factor	1.0
High Speed	3450 RPM
Medium Speed	2600 RPM
Low Speed	1725 RPM
Weight	11 lbs

The installation manual enables a technician, certified by their local/state agency/board, to install, service, repair, and maintain the imPower motor.

Remove the Existing Motor from Pump

WARNING

When servicing the pool pump filter motor, always disconnect the main power from the unit. It is also good practice to confirm that the power is off with a meter.

Step 1: Loosen and remove the screws holding the seal plate to the pump housing. Pull the seal plate/motor assembly from the pump housing.

Step 2: Remove the screws holding the diffuser to the seal plate and remove it.

Step 3: After confirming that the power has been shut off, remove the electrical connections from the existing motor. Remove the conduit and connector from the motor. Note: the conduit and connector will be re-used.

Step 4: To remove the impellor, lock the shaft by placing a wrench or a flathead screwdriver at the opening in the rear. Note: Do not reuse the seal from the existing motor when installing the imPower motor. Remove the screw holding the seal plate onto the motor.

Step 5: Remove the pump motor by removing the four bolts holding the motor to the seal plate of the pump. Also remove the stationary portion of the seal from the seal plate.

Single Speed Connection with Timer

WARNING

When servicing the pool pump filter motor, always disconnect the main power from the unit. It is also good practice to confirm that the power is off with a meter.

These steps as outlined below are for connection of the imPower motor to a single speed timer.

Step 1: Remove the three screws holding the top control enclosure onto the motor. Carefully lift the top panel and turn it over to expose the inside of the terminal box.

Step 2: Run the **L1**, **L2**, and **GROUND** wires from the conduit cable through the ½-14 NPSM threaded opening on the right side of the motor (shaft facing away from you).

Step 3: Connect the **L1** to the opening directly across from the **ORANGE** wire on the terminal block.

Step 4: Connect the **L2** to the opening directly across from the **WHITE** wire on the terminal block.

Step 5: Connect the **GROUND** to the opening directly across from the **GREEN/YELLOW** wire on the terminal block.

Step 6: Screw in the conduit connector into the terminal box on the right side of the terminal box (shaft facing away from you).

Step 7: Carefully fold the extra wires inside the terminal box and place the top control panel back on top of the terminal box.

Step 8: Tighten the three screws into the terminal box while applying light pressure to the top control enclosure.

Step 9: Replace and tighten the screws to mount the seal plate onto the motor.

Step 10: Put a **NEW** pump seal into the seal plate and onto the motor shaft. Handle and lubricate seal per manufacturer's specifications.

Step 11: Replace the impellor. Make sure that the impellor can spin freely in the housing.

Step 12. Replace the diffuser.

Step 13: Replace and tighten the bolts that retain the motor/seal plate assembly to the pump.

Step 14: Prime the pump.

Step 15: Reapply power to the motor.

Note that with this type of connection, the motor will operate on the high speed for 2 hours, and then the motor will automatically switch to the low speed. Note, in the installation manual, there is a section that will show you how to change the default low speed setting.

The total timer on time should be selected so that the pool can meet the total number of turns as required by local/state regulations.

The user can also override the operational speed currently running via the buttons on the top control panel. The override will continue until the motor is powered off by the single speed timer. A new speed can also be selected while in override mode.

Two Speed Connections with Timer

WARNING

When servicing the pool pump filter motor, always disconnect the main power from the unit. It is also good practice to confirm that the power is off with a meter.

If you had a single speed motor prior to this installation, you will need to run new conduit with 4 wires (High Speed, Low Speed, Neutral, and Ground) to properly operate with the two speed timer.

Step 1: Remove the three screws holding the top control enclosure onto the motor. Carefully lift the top panel and turn it over to expose the inside of the terminal box.

Step 2: Run the **HIGH Speed, LOW Speed, L2, and GROUND** wires from the conduit cable through the open on the right side of the motor (shaft facing away from you).

Step 3: Connect the wire for the **HIGH Speed** from the timer to the opening directly across from the **BLACK** wire on the terminal block.

Step 4: Connect the wire for the **LOW Speed** from the timer to the opening directly across from the **RED** wire on the terminal block.

Step 5: Connect the **L2** to the opening directly across from the **WHITE** wire on the terminal block.

Step 6: Connect the **GROUND** to the opening directly across from the **GREEN/YELLOW** wire on the terminal block.

Step 7: Screw in the conduit connector into the terminal box on the right side of the terminal box (shaft facing away from you).

Step 8: Carefully fold the extra wires inside the terminal box and place the top control panel back on top of the terminal box.

Step 9: Tighten the three screws into the terminal box while applying light pressure to the top control enclosure.

Step 10: Replace and tighten the screws to mount the seal plate onto the motor.

Step 11: Put a **NEW** pump seal into the seal plate and onto the motor shaft. Handle and lubricate seal per manufacturer's specifications

Step 12: Replace the impellor. Make sure that the impellor can spin freely in the housing.

Step 13: Replace the diffuser.

Step 14: Replace and tighten the bolts that retain the motor/seal plate assembly to the pump.

Step 15: Prime the pump.

Step 16: Reapply power to the motor.

This connection allows the high speed and low speed to be operated at any duration set by the multi-speed timer. At no point will the motor automatically do down to the default low speed. The timer should be set so that the pool can meet the total number of turns as required by local/state regulations.

The user can also override the operational speed currently being set by the multi-speed timer via the buttons on the top control panel. The override will continue until the motor is either powered off by the multi-speed timer or a new speed is requested by the multi-speed timer. At anytime, another speed can also be selected via the top side control panel buttons.

Automation Controller Signal Line Connection

WARNING

When servicing the pool pump filter motor, always disconnect the main power from the unit. It is also good practice to confirm that the power is off with a meter.

These steps as outlined below are for connection of the imPower motor to an automation controller. You will need the optional low voltage cable connection kit **P/N 391-200-01** (15' cord) or **P/N 391-200-02** (25' cord).

Step 1: Remove the three screws holding the top control enclosure onto the terminal box. Carefully lift the top panel and turn it over to expose the inside of the terminal box.

Step 2: Run the **L1**, **L2**, and **GROUND** wires from the conduit cable through the open on the right side of the motor (shaft facing away from you).

Step 3: Connect **L1** from the automation controller to the opening directly across from the **BLACK** wire on the terminal block.

Step 4: Connect the **L2** to the opening directly across from the **WHITE** wire on the terminal block.

Step 5: Connect the **GROUND** to the opening directly across from the **GREEN/YELLOW** wire on the terminal block.

Step 6: Screw in the conduit connector into the terminal box on the right side of the terminal box (shaft facing away from you).

Step 7: On the rear of the terminal box, remove the small black plug.

Step 8: Plug the connector end of the low voltage cable (**P/N 391-200-01** or **P/N 391-200-02**) into the connector on the underside of the top control panel.

Step 9: Screw in the low voltage conduit onto the rear of the terminal box. Run the low voltage cable to the automation control box.

Step 10: Carefully fold the extra wires inside the terminal box and place the top control panel back on top of the terminal box.

Step 11: The connection of the low voltage wires should be to the **HOT Side** (red and black wire on the top side of the relay). Depending on the manufacturer of the automation controller, you may need to remove the cover plate on these relays to gain access to the terminals.

Step 12: Wire the low voltage wires for the following speeds to be controlled:

High Speed	BLACK (+) WHITE (-)
Medium Speed	BROWN (+) BLUE (-)
Low Speed	RED (+) GREEN (-)

Step 13: Tighten three screws holding down the top control panel.

Step 14: Replace and tighten the screws to mount the seal plate onto the motor.

Step 15: Put a **NEW** pump seal into the seal plate and onto the motor shaft. Handle and lubricate seal per manufacturer's specifications.

Step 16: Replace the impellor. Make sure that the impellor can spin freely in the housing.

Step 17: Replace the diffuser.

Step 18: Replace and tighten the bolts that mounts the motor/seal plate to the pump.

Step 19: Prime the pump.

Step 20: Reapply power to the motor.

The automation controller allows for all three speeds to be selected and operated at any length of time. Note that the currently selected and operating speed must be turned OFF prior to the selection of a new speed. The on time and speeds should be set so that the pool can meet the total number of turns as required by local/state regulations.

The user can also override the operational speed currently being set by the automation controller via the buttons on the top control panel. The override will continue until the motor is either powered off by the automation controller or a new speed is requested by the automation controller. At anytime, another speed can also be selected via the top side control panel buttons.

Changing Default Low Speed

The default low speed can be selected to operate at the medium speed. Please follow all local/state regulations regarding pool motor and timer speed settings.

Step 1: Turn the motor on. Please ensure that the motor is mated to a pump as well as having the pump primed. For a multi-speed timer, please ensure that the HIGH speed is being commanded.

Step 2: After allowing the motor to come to full speed, press and hold the high and medium buttons simultaneously for five seconds. This button selection should be completed within the first two minutes of operation.

The low speed LED will blink for three seconds, followed by 15 blinks of the medium speed LED. The low speed LED blinks for three seconds to identify that the motor is ready for a modification of the default speed, whereas the 15 blinks of the medium speed LED indicates that the default speed has successfully changed to medium speed.

For a single speed timer, the motor will then return to high speed for the duration of the initial two hour high speed operational period, converting the changed default speed after the two hour period.

For a multi-speed timer, the motor will then return to the high speed. The medium speed will then be the second speed selection.

Note: To revert back to low speed default, simply repeat steps 1-4.

imPower Motor Connection Diagram

<p>LINE VOLTAGE CONNECTIONS</p> <p>RED — [] — LOW+</p> <p>BLACK — [] — HIGH+#</p> <p>ORANGE — [] — L1*</p> <p>WHITE — [] — L2</p> <p>GREEN/ YELLOW — [] — ⊕</p>		<p>LOW VOLTAGE (24V MAX.) THROUGH WIRE CONDUIT CABLE</p> <p>HIGH --- BLACK (+) WHITE (-)</p> <p>MEDIUM - BROWN (+) BLUE (-)</p> <p>LOW ---- RED (+) GREEN (-)</p>
<p>* Connect when operating motor with single speed timer. + Connect when operating motor with 2 speed timer. # Connect when operating with automation controller. L2 and Ground should be connected in all operational modes. Connecting to orange and white will allow motor to operate at high speed for 2 hours, then automatically turn down to low speed until power is cycled.</p>		<div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>imPower™ CONTRACTOR HOTLINE 800-683-9144 www.imPowerDealer.com</p> </div>

Accessories:

Description	P/N
15 ft Low Voltage Cable	391-200-01
25 ft Low Voltage Cable	391-200-02



imPower™

Need Additional imPower Help?

Contractor Hotline:
800-683-9144

imPower Website:
www.imPowerDealer.com

