

WATERWARDEN™

POOL SAFETY PRODUCTS

YOU CAN'T AFFORD NOT
TO HAVE ONE!™

To activate 5 year limited warranty, register within 10 days of purchase at
www.thewaterwarden.com
or return completed warranty form on back page to:

Water Warden™ Pool Safety Products
4837 NE 12th Ave
Oakland Park, FL 33334

Water Warden™ Pool Safety Products
Safety Net Installation Instructions for above ground pools

The Water Warden™ Safety Net can be applied to most above ground pools. The basic installation instructions are for any pool without any steps, ladders or decks. If your pool has any of these features, you may purchase a modification kit from the manufacturer. To determine if such a kit is required for your specific pool, or if you are unsure as to whether or not your particular pool can hold a Water Warden™ Pool Net, please call 1-877-402-SAFE, Monday-Friday, 8:00 AM to 5:00 PM for help before you begin.

Necessary Equipment:

Drill

9/64" Drill Bit

Extension Cord

Black magic marker (nonpermanent)

Included Components:

1 Water Warden™ Pool Net with Tensioning System and Guide Cord

Brackets

Hooks (already attached to net)

Drilling template

ASTM Tags (already attached to net)

PLACING THE BRACKETS:

- (1) Removing drilling template from package. Determine the width of pool's top rail, and cut template on the appropriate dotted line.
- (2) Align drilling template with top of any pool upright, directly underneath top rail cap. Using a nonpermanent magic marker, mark the two spots labeled "drill here".
- (3) Repeat step (2) for each upright.
- (4) Drill through marked spots into each upright.
- (5) Place a bracket onto the first drilled upright, with round screw hole on the bottom, and keyhole for hook at the top. (*See Fig. 1*). Use the stainless steel screws provided to attach bracket to upright. For best results, use a drill with speed control to prevent over-tightening of screws.
- (6) Repeat step (5) with remaining brackets and screws, attaching one bracket to each upright with the provided screws.
- (7) Unfold the Water Warden™ Safety Net and spread over top of the pool. Proceed around the pool and clip each hook into its respective bracket.
- (8) Locate tensioning device at center of Water Warden™ Safety Net. The Tensioning Cord is pre-threaded through the pulley system. The ends of the Tensioning Cord are tied to the edges of the Water Warden™ Safety Net. Untie the ends of the Tensioning Cord. Make sure that the two ends of the cord cross one another at an angle of 90°. Attach one Tensioning Cord hook into the closest bracket (use second keyhole on the bracket to fasten this hook). Pull opposite end of the Tensioning Cord taut, and clip the second tensioning hook into its closest bracket. This should provide even tension for the Water Warden™ Safety Net System, to keep the Water Warden™ Safety Net suspended well above the water line.

NOTE: Water level should always be maintained correctly in accordance with pool manufacturer's instructions to ensure safety. Refer to Pool Owner's Manual to determine correct water level.




Fig. 1

WARNING!
THERE IS NO SUBSTITUTE FOR
COMPETENT ADULT SUPERVISION
IN A SWIMMING POOL
ENVIRONMENT! NO POOL SAFETY
PRODUCT IS A GUARANTEE
AGAINST UNAUTHORIZED ACCESS
TO A POOL.

Water Warden™ Pool Net
Five Year Limited Warranty/One Year Full

1. The Manufacturer warrants that the Water Warden™ Safety Net is free from defects in workmanship and materials for a period of five (5) years.
2. This warranty extends to the original purchaser of the Water Warden™ Safety Net.
3. This warranty covers netting fabric, components and hardware but does not cover incidental or consequential damages, metal finishes or installation of the Water Warden™ Safety Net. Installation is warranted by the installer only, and only to the extent of express warranties provided by the installer.
4. In the event of a defect or other failure of the Water Warden™ Safety Net not caused by any misuse, abuse, neglect, improper maintenance or damage to the Water Warden™ Safety Net while in possession of consumer, manufacturer will remedy the failure or defect, without charge to the consumer. The remedy will consist of repair or replacement of the product, at the warrantor's option. Warrantor may choose to provide a consumer repair kit at warrantor's discretion.
5. If manufacturer is unable to provide replacement or repair, a refund will apply as follows: manufacturer will refund what is unserviceable during the first year; after the first year the Water Warden™ Safety Net will be refunded at a rate of 1/84 of MSRP for each month remaining of the 84 months from the original purchase date.
6. If the Water Warden™ Safety Net is reported to be unserviceable, the Water Warden™ Safety Net must be made available to manufacturer's representative to determine its serviceability.
7. We reserve the right to inspect the Water Warden™ Safety Net for any claim against this warranty, to determine the cause of failure or loss of serviceability.

CUSTOMER HAS THE SOLE RESPONSIBILITY FOR PERIODICALLY INSPECTING PRODUCT AND REPORTING DEFECTS OR FAILURES. THIS WARRANTY SHALL NOT APPLY TO ANY ITEM WHICH HAS BEEN IMPROPERLY ASSEMBLED, INSTALLED, USED, STORED, OR MAINTAINED. THIS WARRANTY SHALL NOT APPLY TO ANY ITEM WHICH HAS BEEN REPAIRED OR SERVICED BY ANY OTHER THAN A CERTIFIED REPRESENTATIVE OF THE MANUFACTURER. THIS WARRANTY SHALL NOT APPLY TO ANY ITEM WHICH HAS BEEN SUBJECTED TO EXTERNAL SOURCES OF HEAT SUCH AS, BUT NOT LIMITED TO, POOL HEATERS, COOKING DEVICES OR OPEN FLAMES. THIS WARRANTY SHALL NOT APPLY TO ANY ITEM THAT HAS BEEN SUBJECTED TO MISUSE, ACCIDENTS OR ACTS OF GOD. MANUFACTURER DOES NOT WANT TO CREATE A FALSE SENSE OF SECURITY. THE WATER POOL NET IS NOT INTENDED TO BE A SUBSTITUTE FOR PROPER ADULT SUPERVISION NOT IS IT A GUARANTEE AGAINST ACCESS TO THE POOL.

To file a claim:

Please call 1-877-402-SAFE (7233)
Monday – Friday
8:00 AM – 5:00 PM Eastern Time

Please allow 2-4 weeks for
warranty claims to be processed.

**Water Warden™ Pool Net
Five Year Limited Warranty/One Year Full**

Register your warranty at www.thewaterwarden.com or return this
completed warranty registration and copy of purchase receipt, within ten days of purchase to:

**Water Warden™ Pool Safety Products
4837 NE 12th Ave,
Oakland Park FL 33334**

Purchaser's Name: (please print) _____ Purchase Date: _____
Address: _____
Phone Number: _____ Size of Pool: _____
Dealer's Name: _____
Dealer's Address: _____
Dealer's Phone Number: _____ Dealer's Email: _____
Purchaser's Signature: _____